



$$M(\tilde{\nu}, \delta) = \underbrace{F_{\text{box}}(\delta) \times \Omega_m \frac{\sin\left(\frac{1}{2}\tilde{\nu}\delta\Omega_m\right)}{\frac{1}{2}\tilde{\nu}\delta\Omega_m}}_{\text{ideal}} \times \underbrace{\eta(\tilde{\nu}, \delta)}_{\text{unknown}}$$

$$\eta(\tilde{\nu}, \delta) = a + bi \quad \phi = \arctan\left(\frac{b}{a}\right)$$

